

110-kV-Gemeinschaftsleitung Pkt. Maria Trost - Pkt. Metternich (Bl. 1365)

Masttabelle								
1	2	3	4	5	6	7	8	
Mast-Nr. / Bl. Nr.)	Mast- abstand (Feld- länge) [m]	Mast- typ	Mastart *)	Höhe Mast- standort über NHN *) [m]	Masthöhe über EOK) [m]	Bemerkungen	Mastkoordinaten (UTM-System ETRS 89)	
							Rechtswert	Hochwert
23 / 1259		AA62	WA2+10.0	69.9	47.75	Bestand		
1	230.9	A63	WA2WE+0.0	70.8	32.50		32398204,3	5582357,7
2	223.1	AA61	WA2WE+2.5	72.9	40.75		32397992,6	5582287,7
3	320.8	AA61	T1DB+7.5	76.9	46.50		32397740,6	5582089,4
4	279.2	AA61	T1DB+2.5	80.8	41.50		32397521,3	5581916,9
5	257.1	AA61	T1DB+5.0	87.8	44.00		32397319,3	5581757,9
6	339.9	AA61	T1DB+7.5	89.9	46.50		32397052,3	5581547,9
7	299.2	AA61	T1DB+7.5	92.2	46.50		32396817,2	5581362,9
8	333.9	AA61	WA1DB+5.0	98.9	43.25		32396554,9	5581156,5
9	340.3	AA61	T1DB+10.0	115.5	49.00		32396308,9	5580921,5
10	310.8	AA61	T1DB+5.0	128.1	44.00		32396084,2	5580706,8
11	306.0	AA61	T1DB+2.5	144.7	41.50		32395863,2	5580495,6
12	289.0	AA61	T1DB+0.0	157.3	39.00		32395654,4	5580295,9
13	239.8	AA61	T1DB+0.0	160.1	39.00		32395481,0	5580130,4
14	280.6	AA61	T1DB+2.5	165.1	41.50		32395278,3	5579936,6
15	312.3	AA61	T1DB+2.5	175.4	41.50		32395052,6	5579720,9
16	287.3	AA61	WA1DB+0.0	184.1	38.25		32394844,9	5579522,4
17	190.9	A78	WA2WEDB+0.0	189.4	41.20		32394669,9	5579446,3
18	105.3	A78	SM1+0.0	190.4	41.20		32394616,9	5579355,4
19	204.1	A78	WA1DB+4.0	191.5	45.20		32394459,8	5579225,2
20	260.4 250.4	A78	T1DB+4.0	193.2	46.20		32394257,1 32394264,8	5579062,0 5579068,2
21	247.6 257.6	A78	T1DB+4.0	195.3	46.20		32394064,3	5578906,6
22	257.2	A78	T1DB+4.0	200.3	46.20		32393864,2	5578745,4
23	249.9	A78	T1DB+4.0	203.5	46.20		32393669,6	5578588,6
24	245.6	A78	WA2WEDB+6.0	208.6	47.20		32393478,4	5578434,7
25	306.1	AA61	SM1+10.0	216.1	48.25		32393371,0	5578148,2
1/1380	266.4	A63	WA2WEV1+3.5	216.4	36.00		32393426,5	5577887,8

*)

NHN = Normalhöhennull

EOK = Erdoberkante

Bl. Nr. = Bauleitnummer der zugehörigen Leitung (falls der Mast nicht zu der in der Kopfzeile genannten Leitung gehört)

Mastart: T = Tragmast

WA = Winkel-/Abspannmast

WE = Winkel-/Endmast

ABZW = Abzweigmast

SM = Sondermast